

SPREADER BAR



The Difference Is Performance!

The spreader bar is designed to keep the two floor cleaners from crossing paths within the piping system. It connects to the floor cleaners with the help of clevis hooks.



Product Shown Above	Part Number	Nozzle Usage	Weight (pounds)	Dimensions	Pipe Size
A	A00100119_Spread Bar	Floor Cleaners	6.4	30"	48" and Above

This accessory is for use on the floor cleaners. It adapts to clean the pipe side walls as the cleaner propels forward jetting away debris. It propels water at a 45-degree angles.

Angle Adaptors can also be turned upward to clean bridges within a pipe.

ANGLE ADAPTOR



Product Shown Above	Part Number	Nozzle Usage	Weight (pounds)	Dimensions
A	G00100184	Floor Cleaners	.1	2" x 3/4"

Y CONNECTOR

The Y connector is a necessary tool used in Twin Nozzle operation for larger pipes. This connection tool allows dual use for Floor Cleaners and OMG Nozzles.



Product Shown Above	Part Number	Hose Size	Weight (pounds)	Dimensions	Pipe Size
A	G00100126A	1" - 1 1/4"	8.1	20"	48" and Up
B	G00100126	1" - 1 1/4"	4.65	13"	48" and Up